## **UTLink Public Manifest**



# **Remotely**Control your Prisma & Veo



#### **Minimum System Requirements**

#### Tablet or PC

## Operating System:

- Windows 32/64 bits 7, 8 & 10
- System Memory:
  - 4GB ram recommended Free Disk Space:
  - 200MB of free space required



Sonatest Instrument Supported

#### Important information and recommendations

- · Alpha-numeric values on the virtual instrument keypad are not supported, to edit a name the remote keyboard keys shall be used.
- Refresh rate is based on network performances, images may appear faster on the instrument than on the remote PC or tablet.

### 2017-04-04: UT-Link version 1.4.4

#### **New features**

• none

#### **Fixed**

- Fix security compatibility with some anti-virus software.
- Fix for long device name

## 2017-02-10: UT-Link version 1.4.3

#### New features



New functionnality to maximize the colour palettes when the connection is optimal (Max Color).
 Uncheck to optimize refresh network performances for slower connections.



• New folder button to have a direct access to the instrument internal memory drive and USB drives connected on instrument. ! ONLY for instrument software version 3.13 and higher!



• New button (F11) on corner of the keypad to expand interface window (full screen).

#### <u>Fixed</u>

• General performance enhancements

#### Known issues

• Application need to be restarted if PC goes in sleep mode.

## 2016-02-29: UT-Link version 1.3.3

#### **New features**

- Support new product VEO+.
- Enhanced communication.

#### **Fixed**

• FPS (frame per second rate information) is now correctly displayed.

## 2016-01-29: UT-Link version 1.2

#### **New features**

• Support Windows 10 OS.

#### **Fixed**

• none

# 2015-02-15: UT-Link version 1.1 (first public release)

#### **New features**

• New product enjoy!